

How Do I “Set Distance to 0” with the IMD-1?

When executing an Escalator Step/Skirt Performance Index Test, the EVA-625/MMC-1 will display a prompt;

GO TO STEP 1 RIGHT

SET DISTANCE TO 0

ENT/START TO BEGIN

PRESS ESC TO EXIT

The Process of Setting Distance to Zero is an accuracy enhancing operation internal to the instrument itself and must be done properly to ensure correct results. With one hand, press and HOLD the Friction Shoe Plate fully against the housing of the IMD as shown below.



Then Press the ENT key while continuing to hold the plate fully bottomed, as shown below.



Once the Menu moves on to the next screen, the Friction Shoe Plate can be released.