

Performing a System Reset

Whenever an error should occur with an EVA-625/MMC-1 due to static discharge, low battery operation, or shutting the unit off at a screen other than Main Menu, a System Reset may be necessary to return the instrument to normal operation. Simply turning the unit OFF then ON will not reset the internal variables. The System Reset procedure is outlined below.

From Main Menu of the EVA-625/MMC-1 select;

Configure, press ENT

System Utilities, press ENT

System Reset, press ENT

Yes to Default, press ENT

The unit will then Reboot and all settings are returned to default, you may need to return to the Configure>Set Operations menu to adjust record length, etc.